

Honda Vezel Meter Setting

There are 08 Main menus and Sub-menus under the each Main menu

Ex: Main menu 1 (1/8) → 03 sub-menus

Main menu 2 (2/8) → 03 main sub-menus → 1/3, 2/3 & 3/3 and sub-menus under each main sub menu

=====

1/8 Clock Set → SELECT → 1/3 Time Adjustment (Hr: Min) → SELECT → UP and DOWN Keys for change the values → Press SEL Twice

2/3 Time Adjustment (12h:24H) (Press down key to select)

2/8 Driving Support System Setting

1/3 City Break Active System

1/3 - Activate

2/3 - Deactivate

3/3 - Return

2/3 Reactive Force Pedal (RFP)

1/4 - Strength

2/4 - Weak

3/4 - Standard

4/4 - Return

3/3 Return

3/8 Meter Setting

1/6 Outside Temperature Correction

2/6 Trip A Automatic Reset Timing

1/4 Refueling

2/4 Every Engine Stop (IGN OFF)

3/4 Manual

4/4 Return

3/6 Trip B Automatic Reset Timing

1/4 Refueling

2/4 Every Engine Stop (IGN OFF)

3/4 Manual

4/4 Return

4/6 Ambient Meter Lighting Color Setting

5/6 Random Color ON/OFF

1/3 ON

2/3 OFF

3/3 Return

6/6 Return

4/8 Honda Smart Key System Setting

1/3 Buzzer Volume

1/3 High

2/3 Low

3/3 Return

2/3 Door Handle Operation Buzzer

1/3 Activate

2/3 Deactivate

3/3 Return

3/3 Return

5/8 Light Setting

1/3 Interior Light Lighting Time

1/4 60 Sec

2/4 30 Sec

3/4 15 Sec

4/4 Return

2/3 Auto Lights Sensitivity

1/6 Max

2/6 High

3/6 Mid

4/6 Low

5/6 Min

6/6 Return

3/3 Return

6/8 Door Setting

1/3 Automatic Door Lock Function

1/4 Vehicle Speed Linked

2/4 Shift Lever Linked

3/4 Deactivate

4/4 Return

2/3 Automatic Door Unlock Function

3/3 Return

7/8 Factory Default

1/2 Cancel

2/2 Run